Alarms report 4.2019

Date, Time	Time_ms	StateAfter	MsgNumber	MsgText
08.04.2019, 11:54	43563495829,1435	1 (START)	1081	Compressor block 1 is not ready
08.04.2019, 14:04	43563586514,6875	0 (STOP)	1081	Compressor block 1 is not ready
08.04.2019, 14:04	43563586549,4676	1 (START)	1124	Compressor block 1 - Compressor 2 motor failure
08.04.2019, 14:04	43563586560,6481	0 (STOP)	1124	Compressor block 1 - Compressor 2 motor failure
16.04.2019, 10:23	43571432982,0255	1 (START)	1083	Compressor block 3 is not ready
16.04.2019, 10:23	43571432982,0255	1 (START)	1109	Compressor block 3 - phase monitor alarm
16.04.2019, 10:27	43571435421,8981	1 (START)	1093	Condenser 3 is not ready
16.04.2019, 10:42	43571446120,2315	0 (STOP)	1093	Condenser 3 is not ready
16.04.2019, 10:46	43571448905,6597	0 (STOP)	1083	Compressor block 3 is not ready
16.04.2019, 10:46	43571448905,6597	0 (STOP)	1109	Compressor block 3 - phase monitor alarm
16.04.2019, 10:46	43571449020,7407	1 (START)	1081	Compressor block 1 is not ready
16.04.2019, 10:46	43571449020,7407	1 (START)	1107	Compressor block 1 - phase monitor alarm
16.04.2019, 10:46	43571449148,669	1 (START)	1093	Condenser 3 is not ready
16.04.2019, 10:46	43571449148,669	1 (START)	1083	Compressor block 3 is not ready
16.04.2019, 10:46	43571449148,669	1 (START)	1109	Compressor block 3 - phase monitor alarm
16.04.2019, 10:48	43571450072,4537	1 (START)	1091	Condenser 1 is not ready
16.04.2019, 11:02	43571460111,6319	0 (STOP)	1091	Condenser 1 is not ready
16.04.2019, 11:03	43571460564,3056	0 (STOP)	1081	Compressor block 1 is not ready
16.04.2019, 11:03	43571460564,3056	0 (STOP)	1107	Compressor block 1 - phase monitor alarm
16.04.2019, 11:05	43571462193,831	1 (START)	1082	Compressor block 2 is not ready
16.04.2019, 11:05	43571462193,831	1 (START)	1108	Compressor block 2 - phase monitor alarm
16.04.2019, 11:06	43571462702,0023	1 (START)	1092	Condenser 2 is not ready
16.04.2019, 11:26	43571476970,6713	0 (STOP)	1092	Condenser 2 is not ready
16.04.2019, 11:27	43571477413,4259	0 (STOP)	1082	Compressor block 2 is not ready
16.04.2019, 11:27	43571477413,4259	0 (STOP)	1108	Compressor block 2 - phase monitor alarm
16.04.2019, 13:47	43571574911,6667	0 (STOP)	1093	Condenser 3 is not ready
16.04.2019, 14:38	43571610239,7685	1 (START)	1084	Compressor block 4 is not ready
16.04.2019, 14:38	43571610239,7685	1 (START)	1110	Compressor block 4 - phase monitor alarm
16.04.2019, 14:50	43571618406,4931	1 (START)	1152	Compressor block 4 - Low level of liquid in tank alarm
16.04.2019, 14:50	43571618429,6528	0 (STOP)	1152	Compressor block 4 - Low level of liquid in tank alarm
16.04.2019, 14:51	43571618753,4491	0 (STOP)	1084	Compressor block 4 is not ready
16.04.2019, 14:51	43571618753,4491	0 (STOP)	1110	Compressor block 4 - phase monitor alarm
28.04.2019, 02:59	43583124785,787	1 (START)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 07:48	43583325341,7361	1 (START)	1137	Compressor block 2 - Compressor 3 low oil flow alarm
28.04.2019, 07:48	43583325618,5532	0 (STOP)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 07:48	43583325688,0093	0 (STOP)	1137	Compressor block 2 - Compressor 3 low oil flow alarm
28.04.2019, 07:49	43583325745,8912	1 (START)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 07:51	43583327469,2708	0 (STOP)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 07:57	43583331715,7755	1 (START)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 08:02	43583334791,8982	0 (STOP)	1131	Compressor block 2 - Compressor 1 low oil flow alarm
28.04.2019, 08:06	43583338182,5926	1 (START)	1082	Compressor block 2 is not ready
28.04.2019, 08:07	43583338194,1551	0 (STOP)	1082	Compressor block 2 is not ready
28.04.2019, 08:07	43583338205,7292	1 (START)	1130	Compressor block 2 - Compressor 1 motor failure
28.04.2019, 08:07	43583338217,3495	0 (STOP)	1130	Compressor block 2 - Compressor 1 motor failure
30.04.2019, 11:46	43585490679,9653	1 (START)	1141	Compressor block 3 - Compressor 1 unacceptable refrigerant pressure
30.04.2019, 11:46	43585490702,1528	1 (START)	1139	Compressor block 3 - Compressor 1 motor failure
30.04.2019, 11:46	43585490911,5394	1 (START)	1083	Compressor block 3 is not ready
30.04.2019, 11:46	43585490934,7454	1 (START)	1144	Compressor block 3 - Compressor 2 unacceptable refrigerant pressure
30.04.2019, 11:46	43585490945,7986	1 (START)	1142	Compressor block 3 - Compressor 2 motor failure
30.04.2019, 11:47	43585491038,6111	0 (STOP)	1142	Compressor block 3 - Compressor 2 motor failure
30.04.2019, 11:47	43585491038,6111	0 (STOP)	1144	Compressor block 3 - Compressor 2 unacceptable refrigerant pressure

Alarms report 4.2019

Date, Time	Time_ms	StateAfter	MsgNumber	MsgText
30.04.2019, 11:47	43585491050,9259	0 (STOP)	1139	Compressor block 3 - Compressor 1 motor failure
30.04.2019, 11:47	43585491050,9259	0 (STOP)	1141	Compressor block 3 - Compressor 1 unacceptable refrigerant pressure
30.04.2019, 11:56	43585497677,037	0 (STOP)	1083	Compressor block 3 is not ready
30.04.2019, 13:16	43585553337,0255	1 (START)	1130	Compressor block 2 - Compressor 1 motor failure
30.04.2019, 13:16	43585553348,2986	0 (STOP)	1130	Compressor block 2 - Compressor 1 motor failure
30.04.2019, 13:17	43585553961,2268	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
30.04.2019, 13:17	43585554064,537	0 (STOP)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure