Alarms report 9.2021

Date, Time	Time_ms	StateAfter	MsgNumber	MsgText
07.09.2021, 13:24	44446558679,7106	1 (START)	1082	Compressor block 2 is not ready
07.09.2021, 14:18	44446596392,1528	0 (STOP)	1082	Compressor block 2 is not ready
08.09.2021, 02:54	44447121394,7106	1 (START)	1146	Compressor block 4 - Compressor 1 low oil flow alarm
08.09.2021, 09:09	44447381704,0741	0 (STOP)	1146	Compressor block 4 - Compressor 1 low oil flow alarm
14.09.2021, 10:21	44453431519,5023	1 (START)	1084	Compressor block 4 is not ready
14.09.2021, 10:21	44453431541,7708	0 (STOP)	1084	Compressor block 4 is not ready
18.09.2021, 07:38	44457318625,2431	1 (START)	1010	0.01 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1030	0.03 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1020	0.02 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1040	0.04 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1050	0.05 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1070	0.07 - Evaporator - electrical power is switched off
18.09.2021, 07:38	44457318625,2431	1 (START)	1091	Condenser 1 is not ready
18.09.2021, 07:38	44457318625,2431	1 (START)	1081	Compressor block 1 is not ready
18.09.2021, 07:38	44457318625,2431	1 (START)	1084	Compressor block 4 is not ready
18.09.2021, 07:38	44457318625,2431	1 (START)	1107	Compressor block 1 - phase monitor alarm
18.09.2021, 07:38	44457318625,2431	1 (START)	1110	Compressor block 4 - phase monitor alarm
18.09.2021, 07:38	44457318625,2431	1 (START)	1100	Main power supply interrupted (U = 0 V)
18.09.2021, 07:39	44457318787,3032	1 (START)	1092	Condenser 2 is not ready
18.09.2021, 07:39	44457318787,3032	1 (START)	1093	Condenser 3 is not ready
18.09.2021, 07:39	44457318787,3032	1 (START)	1082	Compressor block 2 is not ready
18.09.2021, 07:39	44457318787,3032	1 (START)	1083	Compressor block 3 is not ready
18.09.2021, 07:39	44457318787,3032	1 (START)	1108	Compressor block 2 - phase monitor alarm
18.09.2021, 07:39	44457318787,3032	1 (START)	1109	Compressor block 3 - phase monitor alarm
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1010	0.01 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1030	0.03 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1020	0.02 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1040	0.04 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1050	0.05 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1070	0.07 - Evaporator - electrical power is switched off
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1091	Condenser 1 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1092	Condenser 2 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1093	Condenser 3 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1081	Compressor block 1 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1082	Compressor block 2 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1083	Compressor block 3 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1084	Compressor block 4 is not ready
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1107	Compressor block 1 - phase monitor alarm
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1108	Compressor block 2 - phase monitor alarm
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1109	Compressor block 3 - phase monitor alarm
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1110	Compressor block 4 - phase monitor alarm
18.09.2021, 09:52	44457411243,6806	0 (STOP)	1100	Main power supply interrupted (U = 0 V)
18.09.2021, 09:52	44457411335,8218	1 (START)	1092	Condenser 2 is not ready
18.09.2021, 09:52	44457411335,8218	1 (START)	1081	Compressor block 1 is not ready
18.09.2021, 09:52	44457411335,8218	1 (START)	1082	Compressor block 2 is not ready
18.09.2021, 09:52	44457411335,8218	1 (START)	1083	Compressor block 3 is not ready
18.09.2021, 09:52	44457411335,8218	1 (START)	1084	Compressor block 4 is not ready
18.09.2021, 09:52	44457411335,8218	1 (START)	1107	Compressor block 1 - phase monitor alarm
18.09.2021, 09:52	44457411335,8218	1 (START)	1108	Compressor block 2 - phase monitor alarm
18.09.2021, 09:52	44457411335,8218	1 (START)	1109	Compressor block 3 - phase monitor alarm
18.09.2021, 09:52	44457411335,8218	1 (START)	1110	Compressor block 4 - phase monitor alarm

Alarms report 9.2021

Date, Time	Time_ms	StateAfter	MsgNumber	MsgText
18.09.2021, 09:52	44457411793,9352	0 (STOP)	1083	Compressor block 3 is not ready
18.09.2021, 09:52	44457411793,9352	0 (STOP)	1109	Compressor block 3 - phase monitor alarm
18.09.2021, 09:53	44457411863,3912	0 (STOP)	1082	Compressor block 2 is not ready
18.09.2021, 09:53	44457411863,3912	0 (STOP)	1108	Compressor block 2 - phase monitor alarm
18.09.2021, 09:55	44457413425,2315	0 (STOP)	1081	Compressor block 1 is not ready
18.09.2021, 09:55	44457413425,2315	0 (STOP)	1107	Compressor block 1 - phase monitor alarm
18.09.2021, 09:57	44457414871,6204	1 (START)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
18.09.2021, 09:57	44457414929,5023	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
18.09.2021, 09:57	44457415103,1366	0 (STOP)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
18.09.2021, 09:57	44457415114,7338	0 (STOP)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
18.09.2021, 09:57	44457415126,3079	1 (START)	1082	Compressor block 2 is not ready
18.09.2021, 10:03	44457419149,6065	0 (STOP)	1084	Compressor block 4 is not ready
18.09.2021, 10:03	44457419149,6065	0 (STOP)	1110	Compressor block 4 - phase monitor alarm
22.09.2021, 11:42	44461487947,7546	0 (STOP)	1092	Condenser 2 is not ready
22.09.2021, 11:42	44461488132,7662	1 (START)	1092	Condenser 2 is not ready
22.09.2021, 11:44	44461489184,6991	0 (STOP)	1092	Condenser 2 is not ready
22.09.2021, 11:44	44461489346,6667	0 (STOP)	1082	Compressor block 2 is not ready
22.09.2021, 11:44	44461489358,3912	1 (START)	1130	Compressor block 2 - Compressor 1 motor failure
22.09.2021, 11:44	44461489370,4977	0 (STOP)	1130	Compressor block 2 - Compressor 1 motor failure
22.09.2021, 11:44	44461489427,7431	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
22.09.2021, 11:44	44461489508,9005	1 (START)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
22.09.2021, 11:45	44461489923,8889	0 (STOP)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
22.09.2021, 11:45	44461489947,1181	0 (STOP)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
23.09.2021, 09:27	44462394092,6968	1 (START)	1092	Condenser 2 is not ready
23.09.2021, 10:03	44462419424,4907	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
23.09.2021, 10:04	44462419748,4491	1 (START)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
23.09.2021, 10:05	44462420149,5718	1 (START)	1082	Compressor block 2 is not ready
23.09.2021, 10:05	44462420172,8819	1 (START)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
23.09.2021, 10:46	44462448786,9097	0 (STOP)	1092	Condenser 2 is not ready
23.09.2021, 11:04	44462461606,3542	0 (STOP)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
23.09.2021, 11:04	44462461652,8935	1 (START)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
23.09.2021, 11:04	44462461652,8935	0 (STOP)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
23.09.2021, 11:04	44462461687,1759	0 (STOP)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
23.09.2021, 11:04	44462461687,1759	0 (STOP)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
23.09.2021, 11:05	44462461964,1319	0 (STOP)	1082	Compressor block 2 is not ready
28.09.2021, 01:19	44467055401,9676	1 (START)	1092	Condenser 2 is not ready
28.09.2021, 01:21	44467056570,3356	1 (START)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
28.09.2021, 01:21	44467056755,4514	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
28.09.2021, 01:22	44467057564,1088	1 (START)	1082	Compressor block 2 is not ready
28.09.2021, 01:22	44467057587,6852	1 (START)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
28.09.2021, 08:59	44467374698,9352	0 (STOP)	1092	Condenser 2 is not ready
28.09.2021, 14:37	44467609232,7199	0 (STOP)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure
28.09.2021, 14:37	44467609232,7199	0 (STOP)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
28.09.2021, 14:37	44467609243,4259	0 (STOP)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
28.09.2021, 14:37	44467609302,037	1 (START)	1130	Compressor block 2 - Compressor 1 motor failure
28.09.2021, 14:37	44467609302,037	1 (START)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
28.09.2021, 14:37	44467609313,0093	0 (STOP)	1130	Compressor block 2 - Compressor 1 motor failure
28.09.2021, 14:37	44467609313,0093	0 (STOP)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure
28.09.2021, 14:37	44467609612,4537	0 (STOP)	1082	Compressor block 2 is not ready
28.09.2021, 17:55	44467746779,0625	1 (START)	1092	Condenser 2 is not ready
28.09.2021, 17:57	44467748294,2014	1 (START)	1138	Compressor block 2 - Compressor 3 unacceptable refrigerant pressure

Alarms report 9.2021

Date, Time	Time_ms	StateAfter	MsgNumber	MsgText
28.09.2021, 17:57	44467748536,9213	1 (START)	1135	Compressor block 2 - Compressor 2 unacceptable refrigerant pressure
28.09.2021, 18:03	44467752468,7384	1 (START)	1082	Compressor block 2 is not ready
28.09.2021, 18:03	44467752491,9907	1 (START)	1132	Compressor block 2 - Compressor 1 unacceptable refrigerant pressure